

Removing the upper grinding head



Rotate the upper grinding head **clockwise** until you hear a "pop", then lift vertically to remove it.

Removing the upper grinding head

Rotate the upper grinding head clockwise until you hear a "pop", then lift vertically to remove it.

Installing the coffee bean hopper



Installing the coffee bean hopper

Align the arrow on the body with the arrow on the coffee bean hopper, insert the coffee bean hopper and rotate clockwise to the desired position.

Installation of upper grinding head



Align the triangle on the upper grinding head with the triangle on the body, place the upper grinding head vertically.



Rotate the upper grinding head **counterclockwise** to the end.

Installation of upper grinding head

Align the triangle on the upper grinding head with the triangle on the body, place the upper grinding head vertically.

Rotate the upper grinding head counterclockwise to the end.